



BEAMZ
MADE
EAZY

152.020_152.022 V1.0

TIGER 9R

QUICK **START** GUIDE

CONTROL MENU

MENU		DESCRIPTION	
SETTINGS	Run mode	DMX	DMX mode
		Sound	Sound mode as master
		Auto	Auto run as master
	DMX Address	001-512	DMX address code
	Lamp	OFF	Lamp controlled by manual
		ON	
	Device Reset	OFF	No Function
		ON	Rest system
	Channel Mode	16CH	16 channels mode
		19CH	19 channels mode
	Screen Rotation	OFF	No Function
		ON	Invert LCD Display
	Invert Pan	OFF	No Function
		ON	Reverse Pan
	Invert Tilt	OFF	No Function
		ON	Reverse Tilt
	Pan-Tilt Swap	OFF	No Function
		ON	Swap Pan and Tilt in system
	Pan-Tilt Encoder	OFF	No Function
		ON	Self correct Pan / Tilt
	DMX Signal	Keep	Hold DMX when signal lost
		Clear	Release DMX when signal missing
	Lamp Setting	OFF	Lamp control by DMX
		ON	Lamp op when power on
	Linear Colour	OFF	No Function
		ON	Half colour
	Load Default	OK	Load factory settings
		Cancel	No Function
MANUAL	Colour	000-255	Manual settings
	Strobe	000-255	
	Dimmer	000-255	
	Gobo	000-255	
	Prism 1	000-255	
	Prism 1 rotation	000-255	
	Prism 2	000-255	
	Prism 2 rotation	000-255	
	Focus	000-255	
	Pan	000-255	
	Pan Fine	000-255	
	Tilt	000-255	
	Tilt Fine	000-255	
	Pan - Tilt Fine	000-255	
	Frost	000-255	
	Lamp&Reset	000-255	
	INFO	Ver	
Dis		Main software version	
MT		Motor software version	
Time Information		Total Lamp	Working time lamp
		Total user	System working time

	Warning	Error	Warning displays
	Turbo Fan Speed	0	Turbo Fan speed
	Hall State	0000011	Static hall position
	Pan Step	+0090	Static Pan position
	Tilt Step	+0311	Static Tilt position
	Authority hours	9999	System working time
FACTORY	Input password		

DMX CHANNELS

16 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	COLOUR WHEEL	000-004	White
		005-009	White+Red
		010-014	Red
		015-019	Red + Orange
		020-024	Orange
		025-029	Orange + Aquamarine
		030-034	Aquamarine
		035-039	Aquamarine + Green
		040-044	Green
		045-049	Green + CT01
		050-054	CT01
		055-059	CT01 + Fluorescent Violet
		060-064	Fluorescent Violet
		065-069	Fluorescent Violet + Pink
		070-074	Pink
		075-079	Pink + Cyan
		080-084	Cyan
		085-089	Cyan + Yellow
		090-094	Yellow
		095-099	Yellow + Light green
		100-104	Light Green
		105-109	Light green + Magenta
		110-114	Magenta
		115-119	Magenta + Lavender
		120-124	Lavender
		125-129	Lavender + CT0 2
		130-134	CT0 2
		135-139	CT0 2 + CTB8000
		140-144	CTB8000
		145-149	CTB8000 + White(Open)
		150-200	Counter clockwise rotation from fast to slow
		201-255	Clockwise rotation from slow to fast
2	STROBE	000-003	No Function
		004-103	Strobe from slow to fast
		104-107	Open
		108-207	Strobe pulse from slow to fast
		208-212	Open
		213-251	Random strobe from slow to fast
		252-255	Open
3	MASTER DIMMER	000-255	Master dimmer 0-100%

4	GOBO WHEEL	000-004	Gobo 1
		005-009	Gobo 2
		010-014	Gobo 3
		015-019	Gobo 4
		020-024	Gobo 5
		025-029	Gobo 6
		030-034	Gobo 7
		035-039	Gobo 8
		040-044	Gobo 9
		045-049	Gobo 10
		050-054	Gobo 11
		055-059	Gobo 12
		060-064	Gobo 13
		065-069	Gobo 14
		070-074	Gobo 1 shake from slow to fast
		075-079	Gobo 2 shake from slow to fast
		080-084	Gobo 3 shake from slow to fast
		085-089	Gobo 4 shake from slow to fast
		090-094	Gobo 5 shake from slow to fast
		095-099	Gobo 6 shake from slow to fast
		100-104	Gobo 7 shake from slow to fast
		105-109	Gobo 8 shake from slow to fast
		110-114	Gobo 9 shake from slow to fast
		115-119	Gobo 10 shake from slow to fast
		120-124	Gobo 11 shake from slow to fast
		125-129	Gobo 12 shake from slow to fast
		130-134	Gobo 13 shake from slow to fast
		135-139	Gobo 14 shake from slow to fast
		140-200	Clockwise rotation from fast to slow
		201-255	Counterclockwise rotation from slow to fast
5	PRISM 1	000-127	Prism 1 off
		128-255	Prism 1 on
6	PRISM 1 ROTATION	000-127	Prism 1 (Static prism 1 angle)
		128-190	Counterclockwise rotation from fast to slow
		191-192	Stop
		193-255	Clockwise rotation from slow to fast
7	PRISM 2	000-127	Prism 2 off
		128-255	Prism 2 on
8	PRISM 2 ROTATION	000-127	Prism 2 (Static prism2 angle)
		128-190	Counterclockwise rotation from fast to slow
		191-192	Stop
		193-255	Clockwise rotation from slow to fast
9	FOCUS	000-255	Adjust focus 0-100%
10	PAN	000-255	Pan movement 0-540°
11	PAN FINE	000-255	Pan Fine
12	TILT	000-255	Tilt movement 0-270°
13	TILT FINE	000-255	Tilt Fine
14	SPEED	000-255	Speed pan, tilt from fast to slow
15	FROST / COLOUR DISC	000-127	Disable frost and colourful disc
		128-191	Enable frost and disable colourful disc
		192-255	Disable frost and enable colourful disc
		000-025	No Function

16	RESET	026-050	Reset motor
		051-060	No Function
		061-085	Reset pan and tilt
		086-099	No Function
		100-109	Lamp off
		110-199	No Function
		200-209	Lamp on
		210-250	No Function
		251-255	Reset system

19 CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	COLOUR WHEEL	000-004	White
		005-009	White+Red
		010-014	Red
		015-019	Red + Orange
		020-024	Orange
		025-029	Orange + Aquamarine
		030-034	Aquamarine
		035-039	Aquamarine + Green
		040-044	Green
		045-049	Green + CT01
		050-054	CT01
		055-059	CT01 + Fluorescent Violet
		060-064	Fluorescent Violet
		065-069	Fluorescent Violet + Pink
		070-074	Pink
		075-079	Pink + Cyan
		080-084	Cyan
		085-089	Cyan + Yellow
		090-094	Yellow
		095-099	Yellow + Light green
		100-104	Light Green
		105-109	Light green + Magenta
		110-114	Magenta
		115-119	Magenta + Lavender
		120-124	Lavender
		125-129	Lavender + CT0 2
		130-134	CT0 2
		135-139	CT0 2 + CTB8000
		140-144	CTB8000
		145-149	CTB8000 + White(Open)
		150-200	Counter clockwise rotation from slow to fast
		201-255	Clockwise rotation from fast to slow
2	STROBE	000-003	No Function
		004-103	Strobe from slow to fast
		104-107	Open
		108-207	Strobe pulse from slow to fast
		208-212	Open
		213-251	Random strobe from slow to fast
		252-255	Open
3	MASTER DIMMER	000-255	Master dimmer 0-100%

4	GOBO WHEEL	000-004	Gobo 1
		005-009	Gobo 2
		010-014	Gobo 3
		015-019	Gobo 4
		020-024	Gobo 5
		025-029	Gobo 6
		030-034	Gobo 7
		035-039	Gobo 8
		040-044	Gobo 9
		045-049	Gobo 10
		050-054	Gobo 11
		055-059	Gobo 12
		060-064	Gobo 13
		065-069	Gobo 14
		070-074	Gobo 1 shake from slow to fast
		075-079	Gobo 2 shake from slow to fast
		080-084	Gobo 3 shake from slow to fast
		085-089	Gobo 4 shake from slow to fast
		090-094	Gobo 5 shake from slow to fast
		095-099	Gobo 6 shake from slow to fast
		100-104	Gobo 7 shake from slow to fast
		105-109	Gobo 8 shake from slow to fast
		110-114	Gobo 9 shake from slow to fast
		115-119	Gobo 10 shake from slow to fast
		120-124	Gobo 11 shake from slow to fast
		125-129	Gobo 12 shake from slow to fast
		130-134	Gobo 13 shake from slow to fast
		135-139	Gobo 14 shake from slow to fast
		140-200	Clockwise rotation from fast to slow
		201-255	Counterclockwise rotation from slow to fast
5	PRISM 1	000-127	Prism 1 off
		128-255	Prism 1 on
6	PRISM 1 ROTATION	000-127	Prism 1 (Static prism1 angle)
		128-190	Counterclockwise rotation from fast to slow
		191-192	Stop
		193-255	Clockwise rotation from slow to fast
7	PRISM 2	000-127	Prism 2 off
		128-255	Prism 2 on
8	PRISM 2 ROTATION	000-127	Prism 2 (Static prism 2 angle)
		128-190	Counterclockwise rotation from fast to slow
		191-192	Stop
		193-255	Clockwise rotation from slow to fast
9	FOCUS	000-255	Adjust focus 0-100%
10	PAN	000-255	Pan movement 0-540°
11	PAN FINE	000-255	Pan Fine
12	TILT	000-255	Tilt movement 0-270°
13	TILT FINE	000-255	Tilt Fine
14	SPEED	000-255	Speed pan, tilt from fast to slow
15	FROST / COLOUR DISC	000-127	Disable frost and colourful disc
		128-191	Enable frost and disable colourful disc
		192-255	Disable frost and enable colourful disc
16	RESET	000-025	No Function

		026-050	Reset motor
		051-060	No Function
		061-085	Reset pan and tilt
		086-099	No Function
		100-109	Lamp off
		110-199	No Function
		200-209	Lamp on
		210-250	No Function
		251-255	Reset system
17	SPEED	000-255	Colour wheel speed from fast to slow
18	SPEED	000-255	Speed form fast to slow for Dimmer/Prism/Prism 2/Frost
19	SPEED	000-255	Gobo speed from fast to slow



BEAMZ

YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT

 **beamZ^{Pro}**

offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!



BEAMZLIGHTING.COM