



Reloop Beatmix 4 & Beatmix 2 - Midi map



Pads - 2 modes

Mode




Mode 






Shift + Mode 



Shift + Mode 



Mode   (engage modes simultaneously)




Deck A / C

(functions combined with 'shift' are highlighted in **this** colour)



Deck B / D

(functions combined with 'shift' are highlighted in **this** colour)



Mixer

